

Bumpsteer Kit

Drill steering arm to 5/8" diameter

Remove tie-rod end from rack

Install adjusting link and rod-end

Adjust your bumpsteer kit by using whichever 7/8" O.D. spacers needed to acquire correct spacing.

This is done by determining the least amount of steering arm movement thru the suspension travel.