

Window Net Installation Instructions

Install net on top bar assembly then install rod end.

Position upper rear mount and weld tab to cage.

Position upper front mount and drill 3/8" hole in roll cage, weld ball stud in place

Position the lower mount on the rocker tab and weld into place

Adjust cable to tighten the net then tighten the 1/8" cable clamp