

STRUT INSTALLATION INSTRUCTIONS

Start by removing the caster/camber mount.

Then remove the strut and spindle assemblies.

Next remove the strut cartridge from the AJE strut assembly.

Position strut housing on balljoint and install nut thru center of housing and tighten to 65 ft. lbs.

Install cartridge, making sure it is seated and tight.

The caster/camber plate installs in the stock location from the underneath side.

Install strut through caster/camber plates.

Install tie-rod ends in steering arms and align front end.